



Position of Parts in Engine Compartment (RHD 1KD-FTV) (Before Aug. 2017 Production)



- A 46 Headlight Assembly RH
- A 47 Short Connector
- A 48 Short Connector
- A 50 Fog Light Assembly RH
- A 51 Noise Filter (Condenser Fan)
- A 52 Front Television Camera Assembly
- A 53 Front Wiper Deicer (Windshield Glass)
- A 56 Front Absorber Control Actuator RH
- A 57 Front Absorber Control Actuator LH
- A 60 Headlight Assembly LH
- A 61 Headlight Assembly RH
- A 62 Headlight Assembly LH
- A 63 Headlight Assembly RH
- A 67 Junction Connector
- A 68 Junction Connector
- A 69 Junction Connector
- A 70 Junction Connector
- A 71 Junction Connector
- A 75 Level Warning Switch (Fuel Filter Assembly)
- A 76 Fuel Filter Warning Switch
- A 77 Fuel Heater Assembly
- A 80 Glow Plug Controller
- A 81 Glow Plug Controller
- A 82 Glow Plug Controller
- A 83 Glow Plug Controller
- A 86 Headlight Assembly LH
- A 87 Headlight Assembly RH
- A 89 Headlight Assembly LH
- A 90 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
- A 91 Headlight Assembly RH
- B 1 Front No. 1 Ultrasonic Sensor LH
- B 2 Front No. 1 Ultrasonic Sensor Center LH
- B 3 Front No. 1 Ultrasonic Sensor Center RH
- B 4 Front No. 1 Ultrasonic Sensor RH
- B 5 Fog Light Assembly LH
- B 6 Fog Light Assembly RH
- B 7 Front No. 1 Ultrasonic Sensor LH
- B 8 Front No. 1 Ultrasonic Sensor Center LH
- B 9 Front No. 1 Ultrasonic Sensor Center RH
- B 10 Front No. 1 Ultrasonic Sensor RH

Position of Parts in Engine Compartment (RHD 1KD-FTV) (Before Aug. 2017 Production)



Position of Parts in Engine Compartment (RHD 1KD-FTV) (Before Aug. 2017 Production)

