



Position of Parts in Engine Compartment (LHD 2TR-FE) (Before Aug. 2017 Production)




C 2 Fuel Injector Assembly No. 2
C 4 Fuel Injector Assembly No. 4
C 7 Ignition Coil Assembly No. 1
C 8 Ignition Coil Assembly No. 2
C 9 Ignition Coil Assembly No. 3
C 10 Ignition Coil Assembly No. 4
C 13 Throttle Body Assembly
C 15 Purge VSV
C 17 Cam Timing Oil Control Valve (Bank 1 Exhaust Side)
C 24 E.F.I. Engine Coolant Temperature Sensor
C 27 Oxygen Sensor (Bank 1 Sensor 2)
C 31 Transmission Revolution Sensor (Counter Gear)
C 33 Intake Mass Air Flow Meter Sub-Assembly
C 38 Vane Pump Assembly
C 39 Cooler Compressor Assembly
C 40 Park/Neutral Position Switch
C 41 Back-Up Light Switch Assembly
C 42 Engine Oil Pressure Switch Assembly
C 43 Transfer Shift Actuator Assembly
C 50 Fuel Injector Assembly No. 1
C 51 Fuel Injector Assembly No. 3
C 52 Cam Position Sensor
C 53 Crank Position Sensor
C 54 Cam Timing Oil Control Valve (Bank 1)
C 55 Air Switching Valve Assembly
C 56 Air Fuel Ratio Sensor (Bank 1 Sensor 1)
C 57 Power Steering Oil Pressure Switch
C 58 Electronically Controlled Transmission Solenoid
C 59 Transmission Revolution Sensor (Turbine)
C 60 Temperature Sensor
C 65 Generator Assembly
C 66 Starter Assembly
C 67 Generator Assembly
C 68 Noise Filter (Ignition)
C 97 Generator Assembly
C137 Air Pressure Sensor
C138 Purge VSV
C139 VVT Sensor (Intake Side)
C140 VVT Sensor (Exhaust Side)
C146 Electronically Controlled Transmission Solenoid
C147 Transmission Revolution Sensor (Counter Gear)
C148 Transmission Revolution Sensor (Turbine)
C156 Vane Pump Assembly
C157 Generator Assembly
C158 Starter Assembly
C159 Park/Neutral Position Switch
D 4 Starter Assembly
h 3 Knock Control Sensor (Bank 1)
p 1 Front Speed Sensor RH
p 2 Front Speed Sensor LH


Position of Parts in Engine Compartment (LHD 2TR-FE) (Before Aug. 2017 Production)




90980-11875




90980-11875




90980-11885




90980-11885




90980-11885



90980-11885



90980-11858



90980-11156




90980-11162




90980-10735




90980-10869




90980-11156




90980-12292




90980-11156




90980-11016




90980-12362




90980-11250




90980-11363



90980-11664




90980-11875



90980-11875




90980-10947



90980-11016



90980-11162



90980-11149

Position of Parts in Engine Compartment (LHD 2TR-FE) (Before Aug. 2017 Production)

C56
Dark Gray (Before Jun.
2015 Production) / Gray
(From Jun. 2015 Production)



90980-11178

C57
Black




90980-11428

C58
Gray



90980-10891

C59
Black



90980-11156

C60
Gray



90980-11162

C65
Black



90980-11964

C66
Black



90980-11400

C67




C68
Gray



90980-10843

C97



C137
Black



90980-10845

C138
Black



90980-12B06

C139
Black




90980-12353

C140
Black



90980-12353

C146
Gray




90980-12712

C147
Black



90980-12B06

C148
Black




90980-12B06

C156
Black



90980-12B06

C157
Black




90980-12A88

C158
Black



90980-12941

C159
Gray




90980-12A23

D4



h3
Black



90980-11875

p1
Black



90980-11900

p2
Black



90980-11900