










Position of Parts in Instrument Panel (RHD Front Bench Seat) (Before Aug. 2017 Production)



A 5 Stop Light Switch Assembly
A 11 Brake Pedal Load Sensing Switch
A 19 Acceleration Sensor
A 54 Stop Light Control Relay Assembly
A 59 Diode (Stop Light)
A 64 Junction Connector
A 65 Junction Connector
A 66 Junction Connector
A 72 Junction Connector
A 85 Stop Light Switch Assembly
C 48 Junction Connector
C 49 Junction Connector
C101 ECM
C102 ECM
C161 ECM
C162 ECM
F 1 Front Passenger Side Squib Circuit
I 1 Clearance Warning ECU Assembly
Q 1 Airbag Sensor Assembly
Q 25 Airbag Sensor Assembly
R 32 Airbag Sensor Assembly
r 2 Clutch Start Switch Assembly
z 1 A/C Amplifier Assembly , A/C Blower Assembly
z 5 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
z 6 Driver Side Squib 2nd Step Circuit , Spiral Cable Sub-Assembly
z 7 Cruise Control Main Switch , Spiral Cable Sub-Assembly , Steering Pad Switch Assembly
z 8 Spiral Cable Sub-Assembly , Steering Pad Switch Assembly

Position of Parts in Instrument Panel (RHD Front Bench Seat) (Before Aug. 2017 Production)



Position of Parts in Instrument Panel (RHD Front Bench Seat) (Before Aug. 2017 Production)

