



Position of Parts in Instrument Panel (LHD Front Separate Seat) (Before Aug. 2017 Production)




H 46	Radio Receiver Assembly
H 47	Radio Receiver Assembly
H 48	Radio & Display Receiver Assembly
H 49	Radio & Display Receiver Assembly
H 50	Radio & Display Receiver Assembly
H 51	Radio & Display Receiver Assembly
H 52	Radio & Display Receiver Assembly
H 53	Navigation Receiver Assembly
H 54	Navigation Receiver Assembly
H 55	Navigation Receiver Assembly
H 56	Navigation Receiver Assembly
H 57	Navigation Receiver Assembly
H 58	Navigation Receiver Assembly
H 59	Navigation Receiver Assembly
H 60	Navigation Receiver Assembly
H 61	Navigation Receiver Assembly
H 62	Navigation Receiver Assembly
H 63	Stereo Component Amplifier Assembly
H 64	Stereo Component Amplifier Assembly
H 65	Stereo Component Amplifier Assembly
H 66	Stereo Component Amplifier Assembly
H 67	Stereo Component Amplifier Assembly
H 68	No. 1 Stereo Jack Adapter Assembly
H 69	Radio & Display Receiver Assembly
H 72	Radio Receiver Assembly
H 81	Antenna Cord Sub-Assembly
H 82	Telematics Transceiver
H 83	Telematics Transceiver


Position of Parts in Instrument Panel (LHD Front Separate Seat) (Before Aug. 2017 Production)




90980-10997




90980-12555




90980-10996




90980-10997




90980-12554




90980-12555




90980-12552




90980-10996




90980-10997




90980-12554




90980-12555




90980-12552




90980-12A52




90980-10996




90980-10997



90980-12555



90980-12553



90980-12554

Position of Parts in Instrument Panel (LHD Front Separate Seat) (Before Aug. 2017 Production)

