
ROOF SIDE INNER REAR PANEL (ASSY)



F29241A


With the quarter panel reinforcement removed.

Symbol meaning

REMOVAL	▲ ▲ : Remove Weld Points
INSTALLATION	● ■ : Plug Weld

F29241B

REMOVAL·INSTALLATION



F29241

INSTALLATION POINT

1 Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
2 *1 is only for installation.
3 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.