REAR FLOOR NO. 5 CROSSMEMBER (ASSY)



F29252A


With the rear floor pan removed.

Symbol meaning

REMOVAL	: Remove Weld Points
INSTALLATION	: Plug Weld

F29252B

REMOVAL·INSTALLATION



F29252

INSTALLATION POINT

1 After welding, apply undercoating to the corresponding parts. (See the paint·coating)

2 After applying the top coat, apply anti-rust agent to the internal panel portion of the closed section structural weld points.