
2. NOTICE ABOUT VEHICLE CONDITION WHEN JACKING UP VEHICLE



: JACK POSITION	Front: Center of crossmember Rear: Center of rear axle housing
: SUPPORT POSITION	Safety stand
: SUPPORT POSITION	Swing arm type lift

F30952