

Ignition (3UR–FE)
51 LAND CRUISER Station Wagon
1
2
3
4
(IG)
10A
INJ
CA1
15
C10
Noise Filter
(Ignition Bank 1)
C17
Noise Filter
(Ignition Bank 2)
C11
C43
Junction
Connector
C4
Ignition Coil Assembly No. 1
C13
Ignition Coil Assembly No. 4
C11
Ignition Coil Assembly No. 6
C51
Ignition Coil Assembly No. 7
C15
Ignition Coil Assembly No. 2
C6
Ignition Coil Assembly No. 3
C8
Ignition Coil Assembly No. 5
C53
Ignition Coil Assembly No. 8
GND
+B
IGF1
IGF2
IGT1
IGT2
IGT3
IGT4
IGT5
IGT6
IGT7
IGT8
ECM
<52–9><52–10>