

Stop Light (Swing Type)
* 1 : w/ BRK LP Relay
* 2 : w/o BRK LP Relay
1
2
3
4
(BAT)
15A
STOP
(IG)
10A
ECU–IG
No. 2
A39
Stop Light Control Relay Assembly
STP
GND
OUT
+B
A30
Stop Light
Switch Assembly
BRK LP Relay
Shift Lock Control ECU Sub–Assembly
<27–2>
Skid Control ECU with Actuator
Assembly<25–4>
ECM<15–14>
<16–17><59–14>
Skid Control ECU
with Actuator
Assembly< 25–4>
K33
Diode
(Stop Light)
High Mounted
Stop Light
T1
Center Stop Light Assembly
HMSL
L48
Noise Filter
(Rear Window Defogger and Stop)
n1
Rear Combination
Light Assembly LH
Y1
Rear Combination Light
Assembly RH
Stop
STP
A1
K2
L2