

Rear Window Defogger (Swing Type)
1
2
3
4
(BAT)
30A DEFOG
(IG)
10A A/C IG
2B
DEFOG Relay
EA1
A/C Amplifier Assembly <44–6>
AK1
NOISE FILTER
NOISE FILTER
A34 Junction Connector
A1 (RHD)
A3 (LHD)
A2
KL1
TL1
T3(A), T4(B) Rear Window Defogger RH (Back Door Glass)
L2
WK1
W4(A), W5(B) Rear Window Defogger LH (Back Door Glass)
K2
DEF
K42 Noise Filter (Rear Window Defogger LH)
DEFB
L48 Noise Filter (Rear Window Defogger and Stop)