

(Cont. next page)

Engine Control (1UR–FE)

* 2 : w/ Air Injection Control Driver
* 3 : w/ Air Injection Control Driver w/ AI–PUMP HTR Relay




(Cont. next page)



(Cont. next page)


Engine Control (1UR–FE)

∗ 1 : Shielded




(Cont. next page)

Engine Control (1UR–FE)



(Cont. next page)




(Cont. next page)


ECT and A/T Indicator (1UR–FE)

21 22 23 24


* 5 : w/ Dynamic Radar Cruise Control



(Cont. next page)



Dynamic Radar Cruise Control (1UR–FE) or Cruise Control (1UR–FE)



LAND CRUISER Station Wagon (EM19U2E)

M