


A47
A26
A24
A22
A25
A45
A52
A32
A37
A34
A19
A12
A10
A20
A42
A3
A1
A2
A11
A6
A4
A14
A8
A9
A5
A13
A7
A16

A 1 Headlight Assembly LH
A 2 Headlight Assembly LH
A 3 Headlight Assembly LH
A 4 High Pitched Horn Assembly
A 5 Low Pitched Horn Assembly
A 6 Front Airbag Sensor RH
A 7 Front Airbag Sensor LH
A 8 Engine Hood Courtesy Switch
A 8 Engine Hood Courtesy Switch
A 9 Condenser Blower Motor Assembly
A 10 Headlight Assembly RH
A 11 Headlight Assembly RH
A 12 Headlight Assembly RH
A 13 A/C Pressure Sensor
A 14 Ambient Temperature Sensor
A 16 Windshield Washer Motor and Pump Assembly
A 19 Security Horn Assembly
A 20 Wireless Door Lock Buzzer
A 22 Windshield Wiper Motor Assembly
A 24 Skid Control ECU with Actuator Assembly
A 25 Skid Control ECU with Actuator Assembly
A 26 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
A 32 Noise Filter
A 34 Junction Connector
A 37 Junction Connector
A 42 Winch Main Relay (No.1 Magnet Switch Assembly)
A 45 Side Turn Signal Light Assembly LH
A 47 Side Turn Signal Light Assembly RH
A 52 ECM


A 1
Gray



A 2
Black



A 3
Black



A 4
Black



A 5
Black



A 6
Yellow



A 7
Yellow



A 8
Black



(Except U.K.)

A 8
Dark Gray




(U.K.)


A 9
Black




A 10
Gray




A 11
Black



A 12
Black




A 13
Black




A 14
Black



A 16
Gray



A 19
Black




A 20
Black




A 22
Black




A 24
Black




A 25
Black




A 26
Gray




A 32
Black




A 34
White



A 37
Blue



A 42
Black



A 45
Gray



A 47
Gray



A 52
Black

