


(*1)
(*2)
U2
U1
D20
D14
D3
D2
D19
D1
D4
* 1:Cold Area Spec.
* 2:Except Cold Area Spec.
z17
z29
z30
z18
z31
z33
z32

D 1 Generator Assembly
D 2 Starter Assembly
D 3 Starter Assembly
D 4 Generator Assembly
D 14 Starter Assembly
D 19 Generator Assembly
D 20 Starter Assembly

U 1 Knock Control Sensor (Bank 2)
U 2 Knock Control Sensor (Bank 1)

z 17 Front Speed Sensor RH
z 18 Front Speed Sensor LH
z 29 Winch Main Relay (No.1 Magnet Switch Assembly)
z 30 Winch Main Relay (No.1 Magnet Switch Assembly)
z 31 With Magnet Switch Winch Motor Assembly
z 32 With Magnet Switch Winch Motor Assembly
z 33 With Magnet Switch Winch Motor Assembly

D 1




D 2

Black



D 3




D 4


Black




D 14



D 19




D 20




U 1

Black



U 2

Black



z 17

Black




z 18


Black




z 29



z 30



z 31



z 32

Gray



z 33

