

Instrument Panel Wire
Instrument Panel No.2 Wire
Instrument Panel No.5 Wire
F1
Instrument Panel No.2 Wire
Engine Room Main Wire
E3
Roof Wire
Instrument Panel No.3 Wire
Front Door RH Wire
E1
Floor No.2 Wire
Front Door LH Wire
Floor No.2 Wire
Floor Wire
E2
Floor Wire