

SAFETY

Active Head Rest System

- Active headrests are provided*, which move up and forward almost instantly in the event of a rear-end collision when the force of the occupant body is applied to the seat back and reduce the distance between the occupant's head and the headrest.
- The active headrest consists of the lower unit, cable and upper unit.
- When the lower unit built into the seat back is pressed by the occupant's lumbar as the occupant's body slides down during a rear-end collision, the cable is pulled and the headrest is moved up and forward by the upper unit, reducing the distance between the occupant's head and the headrest.

*: Standard on European models and Chinese VX grade models





080BO33Y

Normal Position **Operating Position**