■ FUNCTION

The Bluetooth hands-free system has the following functions:

Function			Outline
Calling with a Bluetooth Phone	Phone by Dialing		The user can call by inputting a telephone number.
	By Phonebook		The user can call by using the phonebook data that has been transferred from the user's cellular phone. The user can register up to 1000 numbers in the phonebook.
	By Call History	Dialed Number	The user can call by selecting a previously dialed number. The system remembers up to 10 dialed numbers. If more than 10 numbers have been dialed, the oldest number will no longer be remembered.
		Received Call	The user can call by selecting the telephone number of a received call. When a call is received, the system will remember the last 10 numbers. If more than 10 calls have been received, the oldest number will no longer be remembered.
		Missed Call	The user can call by selecting the telephone number of a missed call. The system remembers up to 10 missed call numbers. If more than 10 calls have been missed, the oldest number will no longer be remembered.
		All Call History	The user can call by selecting a telephone number from all call history. However, the number of telephone numbers in the call history that the user can use is limited while driving.
	By Speed Dial		The user can call by using registered telephone numbers selected from the phonebook, dialed numbers or received calls.
	By Voice Recognition	Dialing by Name	The user can call by giving a name registered in the phonebook.
		Dialing by Phone Number	The user can call by giving a desired number.
	By Point Of Interest (POI)		The user can call by operating a switch when "Call" is displayed on the navigation screen.
Receiving a Call Using a Bluetooth Phone			When a call is received, the receive screen is displayed with a sound.
Talking on a Bluetooth Phone			While the user is talking on the phone, the talking screen is displayed.

Function		Outline
Changing Bluetooth Phone Settings	Speed Dial Registration	The user can register a desired telephone number from the phonebook, dialed numbers or received calls. Up to 18 speed dialed numbers can be registered.
	Volume Settings	The user can set the volume.
		Automatic volume settings for high speed: When vehicle speed is 80 km/h (50 mph) or more, the volume automatically increases. The volume returns to the previous volume setting when vehicle speed drops to 70 km/h (43 mph) or less.
	Phonebook Settings	Transferring a telephone number: The user can transfer telephone numbers from the Bluetooth phone to the system. Up to 1000 data items (up to 3 numbers per entry) can be registered in the phonebook.
		Automatically transferring a telephone number: When a PBAP compatible phone is connected, the phonebook data of the phone can be automatically transferred.
		Registering phone numbers: The user can register phone numbers in the phonebook.
		Editing a name: The user can edit a name that has been entered. If no name has been entered, the number is displayed.
		Editing a phone number: The user can register a phone number to “Phone#1”, “Phone#2” or “Phone#3”.
		Deleting data: The user can delete the data.
		Deleting all the phone data: The user can delete all the phone data.
		Deleting the call history data: The user can delete the call history data individually or all at once.
	Screen Settings	Receiving call display: The user can select the method of the receiving call display.
		Checking the Bluetooth connection during startup: When the engine switch is turned on (IG) or on (ACC) and the Bluetooth is automatically connected, the connection check will be displayed.
		Initializing the settings: The user can initialize the settings.

Function		Outline
Registering and selecting a Bluetooth Phone	Bluetooth Phone Registration	In order to use the hands-free function of a Bluetooth phone, it is necessary to register it in the navigation receiver assembly. Once a phone is registered, the hands-free function becomes available automatically.
	Bluetooth Phone Selection	When 2 or more registered Bluetooth phones are in the cabin, it is necessary to select which phone to use to prevent the lines from being crossed. Only the selected phone is available for use as a hands-free phone. The phone registered last is automatically selected.
	Bluetooth Information Confirmation and Editing	The user can set, change and initialize the information of the Bluetooth phone displayed on the screen.
	Deleting a Bluetooth Phone	The user can delete a registered Bluetooth phone from the navigation receiver assembly.
Bluetooth Phone Message	Checking Message	The user can transmit the messages (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail) received on the Bluetooth phone to the audio head unit. ● Displaying the message text. ● Reading out of the message. ● Calling a Short Message Service (SMS)/Multimedia Messaging Service (MMS) message sender's phone number.
	Reply Message	The user can reply to a message (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail) received on the Bluetooth phone.
	Editing Reply Message	The user can edit.
	Displaying Mail List	The user can display the list of received messages (Short Message Service (SMS)/Multimedia Messaging Service (MMS)/e-mail).