
(Cont. next page)

Engine Control (3UR–FE) (From Aug. 2015 Production)


∗ 4 : w/ Air Injection Control Driver



(Cont. next page)

Engine Control (3UR–FE) (From Aug. 2015 Production)


∗ 4 : w/ Air Injection Control Driver



(Cont. next page)

Engine Control (3UR–FE) (From Aug. 2015 Production)


∗ 4 : w/ Air Injection Control Driver



(Cont. next page)


Engine Control (3UR–FE) (From Aug. 2015 Production)

* 1 : Shielded
* 4 : w/ Air Injection Control Driver



(Cont. next page)


Engine Control (3UR–FE) (From Aug. 2015 Production)



(Cont. next page)

Engine Control (3UR–FE) (From Aug. 2015 Production)

* 1 : Shielded




(Cont. next page)

Engine Control (3UR–FE) (From Aug. 2015 Production)

Cruise Control (3UR–FE) (From Aug. 2015 Production)


25 26 27 28

* 1 : Shielded




(Cont. next page)

ECT and A/T Indicator (3UR–FE) (From Aug. 2015 Production)



(Cont. next page)

ECT and A/T Indicator (3UR–FE) (From Aug. 2015 Production)



ECT and A/T Indicator (3UR–FE) (From Aug. 2015 Production)

* 2 : Before Aug. 2017 Production
* 3 : From Aug. 2017 Production

