
(Cont. next page)


Engine Control (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)

* 4 : w/ Air Injection Control Driver



(Cont. next page)


Engine Control (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)



(Cont. next page)

Engine Control (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)


∗ 4 : w/ Air Injection Control Driver



(Cont. next page)

Engine Control (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)


* 1 : Shielded
* 4 : w/ Air Injection Control Driver



(Cont. next page)


Engine Control (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)

* 1 : Shielded
* 7 : w/ Entry & Start System
* 8 : w/o Entry & Start System




(Cont. next page)

Cruise Control (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)



(Cont. next page)

ECT and A/T Indicator (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)



ECT and A/T Indicator (1GR–FE) (From Aug. 2015 Production until Aug. 2017 Production)

