

(Cont. next page)


Power Source (From Jan. 2013 Production until Aug. 2015 Production Except China)



(Cont. next page)

Power Source (From Jan. 2013 Production until Aug. 2015 Production Except China)




Power Source (From Jan. 2013 Production until Aug. 2015 Production Except China)
* 5 : w/ Entry & Start System
* 6 : w/o Entry & Start System
9
10
11
12
A
B
W
C
R(*6)
D
G
B
W
1 2A
1 3A
47 2D
5A AM1
TAIL Relay
ACC Relay
IG1 NO. 1 Relay
IG1 NO. 2 Relay
IG1 NO. 3 Relay
15A TAIL
10A PANEL
7. 5A ACC
15A CIG
5A LH–IG
20A 4WD
5A ECU–IG No. 1
10A BK/UP LP
5A WINCH
10A A/C IG
10A ECU–IG No. 2
15A RR WIPER
20A WSH
30A WIPER
7. 5A OBD
7. 5A A/C
15A TI&TE
30A FR P/SEAT RH
15A MIR
30A FR P/SEAT LH
15A PWR OUTLET
15A INVERTER
25A S/ROOF
30A PSB
20A FR DOOR LH
20A FR DOOR RH
25A DOOR NO. 1
20A RR DOOR LH
20A RR DOOR RH
7. 5A RR FOG
E P (*6)
F P (*5)
45 2D
G G
43 2D
62 2D
W–B
4
E62
Junction Connector
1
W–B
E1
G
22 3C
IG NO. 4 Relay
STRG HTR Relay
5A ECU–IG No. 4
20A SEAT–HTR
5A ECU–IG No. 3
10A SEAT–A/C FAN
10A STRG HTR
15A DOOR DL
20A AHC–B
10A AHC–B No. 2
10A TV
30A B/DR CLSR RH
30A B/DR CLSR LH
8 3C
W–B
E3