
(Cont. next page)

Engine Control (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)


* 2 : w/ Air Injection Control Driver
* 3 : w/ Air Injection Control Driver w/ AI–PMP HTR Relay
* 6 : w/ Heated Windshield Defroster
* 7 : w/o Heated Windshield Defroster



(Cont. next page)

Engine Control (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)


* 2 : w/ Air Injection Control Driver
* 3 : w/ Air Injection Control Driver w/ AI–PMP HTR Relay
* 4 : w/ Air Injection Control Driver w/o AI–PMP HTR Relay



(Cont. next page)


Engine Control (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)

* 1 : Shielded



(Cont. next page)


Engine Control (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)



(Cont. next page)


Engine Control (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)

ECT and A/T Indicator (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)



(Cont. next page)

ECT and A/T Indicator (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)




(Cont. next page)

ECT and A/T Indicator (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)

Dynamic Radar Cruise Control (1UR–FE) or Cruise Control (1UR–FE) (From Jan. 2013 Production until Aug. 2015 Production Except China)

25 26 27 28



Dynamic Radar Cruise Control (1UR–FE) or Cruise Control (1UR–FE)
(From Jan. 2013 Production until Aug. 2015 Production Except China)

