
F RELAY LOCATIONS

① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	Engine Compartment Left


(Before Aug. 2015 Production)

* 1:DEFOG Relay
* 2:EDU 2 Relay
* 3:EDU 1 Relay
* 4:IG1 NO.5 Relay
* 5:EFI NO.2 Relay (3UR-FE, 1UR-FE)
  A/F Relay (1VD-FTV w/ DPF)
* 6:RR A/C Relay
* 7:ST Relay (Gasoline Before Jan. 2013 Production, Gasoline From Jan. 2013 Production China)
  DOME CUT Relay (w/ DOME CUT Relay)
* 8:C/OPN Relay (Gasoline Before Jan. 2012 Production)
  AI-PMP HTR Relay (1UR-FE, 1GR-FE)
  SUB PUMP Relay (Diesel)
* 9:SECURITY HORN Relay
* 10:FR FOG Relay
* 11:PTC HTR1 Relay
* 12:ST CUT Relay
* 13:CDS FAN Relay
* 14:PTC HTR2 Relay
* 15:BRK LP Relay
* 16:MG CLT Relay
* 17:DEICER Relay
  (w/ Front Window Deicer)
  P/W MAIN Relay
  (Driver's Door Only Jam Protection)
* 18:PTC HTR3 Relay
* 19:ST Relay
  (Gasoline From Jan. 2013 Production Except China, Diesel)
* 20:HEAD HI Relay
* 21:HEAD LO Relay
* 22:60A AHC (Before Jan. 2013 Production)
  (for High Current)
  100A SUB-R/B
  (w/ Heated Windshield Defroster)
  (for High Current)
* 23:50A HTR (for High Current)
* 25:150A LH-J/B (for High Current)
* 26:180A ALT (Except 1GR-FE)
  (for High Current)
  140A ALT (1GR-FE)
  (for High Current)
* 27:50A A/PUMP NO.1 (Gasoline)
  (for High Current)
  80A GLOW1 (Diesel)
  (for High Current)
* 28:80A GLOW2 (for High Current)
* 29:40A MAIN (for High Current)
* 30:AHC Relay
* 31:GLOW 1 Relay
* 32:GLOW 2 Relay
* 33:VSCS HTR Relay (1VD-FTV)
  AI-VSV Relay
  (1UR-FE, 1GR-FE)
* 34:30A PBD (for High Current)



1 : Engine Room R/B Assembly : Engine Room J/B Assembly	**Engine Compartment Left**

(Gasoline Before Aug. 2015 Production)




F RELAY LOCATIONS

1 : Engine Room R/B Assembly : Engine Room J/B Assembly	**Engine Compartment Left**

(Diesel Before Aug. 2015 Production)


Unit A



① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

(Before Aug. 2015 Production)


Unit B



F RELAY LOCATIONS


① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

Unit E




① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

(Before Aug. 2015 Production)



F RELAY LOCATIONS

(1) : Engine Room R/B Assembly : Engine Room J/B Assembly	**Engine Compartment Left**




① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

(Before Aug. 2015 Production)

Unit C


* 1:15A A/F (Gasoline)
15A EFI MAIN2 (Diesel w/o DPF)
25A EFI MAIN2 (Diesel w/ DPF)



F RELAY LOCATIONS


① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

(From Aug. 2015 Production)



① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

Unit A



* 1:140A ALT (1GR-FE) (for High Current)
  180A ALT (Except 1GR-FE) (for High Current)
* 3:40A VGRS (for High Current)
* 4:30A ST (for High Current)
* 5:30A ABS NO.2 (for High Current)
* 6:50A ABS NO.1 (for High Current)
* 7:50A AIR PMP NO.2 (Gasoline) (for High Current)
  80A GLOW NO.2 (Diesel) (for High Current)
* 8:80A J/B LH-B (for High Current)
* 9:50A AIR PMP NO.1 (Gasoline) (for High Current)
  80A GLOW NO.1 (Diesel) (for High Current)
* 10:80A P/I-B (for High Current)
* 11:140A J/B LH-AM (for High Current)
* 12:60A R/B NO.2 (for High Current)
* 13:50A HTR (for High Current)
* 14:50A AHC (for High Current)
* 15:50A A/C RR NO.1 (for High Current)
* 16:50A J/B RH-AM (for High Current)
* 17:40A SUB BATT (for High Current)
* 18:30A PBD (for High Current)
* 19:30A DEF (for High Current)
* 20:30A H-LP CLN (for High Current)
* 21:50A PTC HTR NO.1 (for High Current)
* 22:50A PTC HTR NO.2 (for High Current)
* 23:50A PTC HTR NO.3 (for High Current)
* 24:40A H-LP MAIN NO.1 or H-LP RH
  (for High Current)
* 25:40A H-LP MAIN NO.2 or H-LP LH
  (for High Current)
* 26:30A HWD NO.1 (for High Current)
* 27:30A HWD NO.2 (for High Current)


F RELAY LOCATIONS

① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

(From Aug. 2015 Production)


Unit B

* 1:LHD Before Aug. 2016 Production
* 2:LHD From Aug. 2016 Production, RHD



: Engine Room R/B Assembly : Engine Room J/B Assembly	**Engine Compartment Left**


Unit C



F RELAY LOCATIONS

① : Engine Room R/B Assembly ⬭ : Engine Room J/B Assembly	**Engine Compartment Left**

(From Aug. 2015 Production)



1 : Engine Room R/B Assembly : Engine Room J/B Assembly	**Engine Compartment Left**

* 1:1GR-FE, 1UR-FE
  Except 180A Generator Type
* 2:3UR-FE, 1UR-FE
  180A Generator Type
* 3:1VD-FTV

