

Engine Wire
C11
C12
Sensor Wire
C10
A5
A4
Engine Room Main Wire
Engine No.6 Wire
Skid Control Sensor Wire
Engine No.7 Wire
A1
A2
Skid Control Sensor Wire
Engine No.2 Wire
Engine Room No.4 Wire