


* 3:Cold Area Spec.
* 4:Except Cold Area Spec.


B 5 Fog Light Assembly LH
B 6 Fog Light Assembly RH
B 9 No.1 Ultrasonic Sensor RH
B 10 No.1 Ultrasonic Sensor LH

D 12 Starter Assembly
D 13 Starter Assembly


j 1 Generator Assembly
j 2 Generator Assembly

z 17 Front Speed Sensor RH
z 18 Front Speed Sensor LH
z 29 Winch Main Relay (No.1 Magnet Switch Assembly)
z 30 Winch Main Relay (No.1 Magnet Switch Assembly)
z 31 With Magnet Switch Winch Motor Assembly
z 32 With Magnet Switch Winch Motor Assembly
z 33 With Magnet Switch Winch Motor Assembly
z 34 Front Height Control Sensor Sub-Assembly RH
z 35 Front Height Control Sensor Sub-Assembly LH
z 64 Suction Control Valve (Injection or Supply Pump Assembly)
z 65 Fuel Temperature Sensor (Injection or Supply Pump Assembly)
z 66 DC Motor and Nozzle Vane Position Sensor LH
z 67 DC Motor and Nozzle Vane Position Sensor LH
z 68 Pressure Discharge Valve


B 5
Black




B 6
Black



B 9
Black




B 10
Black




D 12
Black




D 13



j 1



j 2




z 17
Black




z 18
Black




z 29




z 30




z 31




z 32
Gray




z 33



z 34
Black



z 35
Black




z 64
Gray




z 65
Gray



z 66
Black



z 67
Gray



z 68
Gray

