

Engine Room
Main Wire
Engine Wire
C3
C6
C5
A3
A4
Skid Control
Sensor Wire
A1
Engine No.2
Wire
A2
Skid Control
Sensor Wire
D1
Engine Room
No.4 Wire
C4