

Engine Wire
C12
C11
Sensor Wire
C10
A3
A4
Engine Room Main Wire
Engine No.6 Wire
Skid Control Sensor Wire
Engine No.7 Wire
A1
A2
Skid Control Sensor Wire
Engine Room No.4 Wire
Engine No.2 Wire