


F5
F36
F11
F19
F20
F73
F41
F7
F42
F8
F35
F10

F 5 Amplifier Antenna Assembly
F 7 Front No.2 Speaker Assembly RH , Short Connector
F 8 Front No.2 Speaker Assembly LH , Short Connector
F 10 A/C Control Assembly
F 11 Hazard Warning Signal Switch Assembly
F 19 Radio Receiver Assembly
F 20 Junction Connector
F 35 Radio Receiver Assembly
F 36 Radio Receiver Assembly
F 41 Short Connector
F 42 Short Connector
F 73 Junction Connector


F 5
White




F 7
White




F 8
White




F 10
White




F 11
Gray




F 19
White



F 20
Gray




F 35
White




F 36
White



F 41
White



F 42
White



F 73
Blue

