



(*3)
(*2)
F114
F113
F126
F121
F112
F130
F41
F7
F42
F8
F133
F10
F132
* 2:w/ Radio Receiver Assembly
* 3:w/o Radio Receiver Assembly

F 7 Front No.2 Speaker Assembly RH , Short Connector
F 8 Front No.2 Speaker Assembly LH , Short Connector
F 10 A/C Control Assembly
F 41 Short Connector
F 42 Short Connector
F 112 Radio Receiver Assembly
F 113 Radio Receiver Assembly
F 114 Radio Receiver Assembly
F 121 Option Connector (Radio Receiver Assembly)
F 126 Option Connector (Radio Receiver Assembly)
F 130 Hazard Warning Signal Switch Assembly
F 132 Temperature Control Switch Assembly RH
F 133 Temperature Control Switch Assembly LH


F 7
White




F 8
White




F 10
White




F 41
White



F 42
White




F112
White




F113
White




F114
White




F121
White




F126
White



F130
Gray



F132
White



F133
White

