

Instrument Panel No.2 Wire
F1
Instrument Panel No.5 Wire
Instrument Panel Wire
Instrument Panel No.2 Wire
Roof Wire
E3
E1
Engine Room Main Wire
Front Door LH Wire
Instrument Panel No.3 Wire
Floor Wire
Floor No.2 Wire
Floor Wire
Front Door RH Wire
Switch Wire
Floor No.2 Wire
E2
Dash Wire