


F42
F73
F20
F19
F35
F36
F5
F8
A39
A29
F41
F7
A27
A28
A31
A30
F10
F11


A 27 Four Wheel Drive Control ECU
A 28 Four Wheel Drive Control ECU
A 29 Front Blower with Fan Motor Sub-Assembly
A 30 Stop Light Switch Assembly
A 31 Accelerator Pedal Sensor Assembly
A 39 Stop Light Control Relay Assembly

F 5 Amplifier Antenna Assembly
F 7 Front No.2 Speaker Assembly RH , Short Connector
F 8 Front No.2 Speaker Assembly LH , Short Connector
F 10 A/C Control Assembly
F 11 Hazard Warning Signal Switch Assembly
F 19 Radio Receiver Assembly
F 20 Junction Connector
F 35 Radio Receiver Assembly
F 36 Radio Receiver Assembly
F 41 Short Connector
F 42 Short Connector
F 73 Junction Connector


A 27
Black




A 28
Black




A 29
White




A 30
Gray



A 31
Black




A 39
Black




F 5
White




F 7
White




F 8
White




F 10
White




F 11
Gray




F 19
White



F 20
Gray




F 35
White




F 36
White



F 41
White



F 42
White



F 73
Blue

