

Instrument Panel Wire
Instrument Panel No.2 Wire
Instrument Panel No.5 Wire
F1
Instrument Panel No.2 Wire
Engine Room Main Wire
Roof Wire
E3
E4
Instrument Panel No.3 Wire
Front Door RH Wire
Engine Room Main Wire
Floor No.2 Wire
Front Door LH Wire
Floor No.2 Wire
Console Box Wire
Floor Wire
E5
Floor Wire
Radio Wiring Sub-Assembly
Switch Wire