
























* 1 : 6 Speaker
* 2 : 4 Speaker


F19(C), F35(A), F36(B), F55(D)
Radio Receiver Assembly



















JK1
White



JL1
White



zE1
Brown

