


Position of Parts in Engine Compartment <RHD 1VD-FTV Before Aug. 2015 Production>


* 7: Before Jan. 2012 Production

* 8: From Jan. 2012 Production



- A 1 Headlight Assembly LH
- A 2 Headlight Assembly LH
- A 3 Headlight Assembly LH
- A 4 High Pitched Horn Assembly
- A 5 Low Pitched Horn Assembly
- A 6 Front Airbag Sensor RH
- A 7 Front Airbag Sensor LH
- A 8 Engine Hood Courtesy Switch
- A 9 Condenser Blower Motor Assembly
- A 10 Headlight Assembly RH
- A 11 Headlight Assembly RH
- A 12 Headlight Assembly RH
- A 13 A/C Pressure Sensor
- A 14 Ambient Temperature Sensor
- A 16 Windshield Washer Motor and Pump Assembly
- A 17 Headlight Cleaner Control Relay and Motor
- A 19 Security Horn Assembly
- A 20 Wireless Door Lock Buzzer
- A 22 Windshield Wiper Motor Assembly
- A 23 Front Wiper Deicer (Windshield Glass)
- A 24 Skid Control ECU with Actuator Assembly
- A 25 Skid Control ECU with Actuator Assembly
- A 26 Brake Fluid Level Warning Switch (Brake Master Cylinder Reservoir Assembly)
- A 32 Noise Filter
- A 34 Junction Connector
- A 37 Junction Connector
- A 42 Winch Main Relay (No.1 Magnet Switch Assembly)
- A 43 Level Warning Switch (Fuel Filter Assembly)
- A 45 Side Turn Signal Light Assembly LH
- A 47 Side Turn Signal Light Assembly RH
- A 48 Turbo Motor Driver
- A 51 Clogging Switch (Fuel Filter Assembly)
- A 52 ECM
- A 53 Headlight Assembly LH
- A 54 Headlight Assembly LH
- A 55 Front Television Camera Assembly
- A 57 Headlight Assembly RH
- A 58 Headlight Assembly RH
- A 59 Headlight Cleaner Control Relay and Motor
- A 64 Front Tire Pressure Warning Antenna

Position of Parts in Engine Compartment <RHD 1VD-FTV Before Aug. 2015 Production>



Position of Parts in Engine Compartment <RHD 1VD-FTV Before Aug. 2015 Production>

