




- A 27 Four Wheel Drive Control ECU
- A 28 Four Wheel Drive Control ECU
- A 29 Front Blower with Fan Motor Sub-Assembly
- A 30 Stop Light Switch Assembly
- A 31 Accelerator Pedal Sensor Assembly
- A 39 Stop Light Control Relay Assembly

- F 5 Amplifier Antenna Assembly
- F 7 Front No.2 Speaker Assembly RH , Short Connector
- F 8 Front No.2 Speaker Assembly LH , Short Connector
- F 10 A/C Control Assembly
- F 11 Hazard Warning Signal Switch Assembly
- F 19 Radio Receiver Assembly
- F 20 Junction Connector
- F 35 Radio Receiver Assembly
- F 36 Radio Receiver Assembly
- F 41 Short Connector
- F 42 Short Connector
- F 73 Junction Connector

Position of Parts in Instrument Panel <RHD Front Bench Seat Type Before Aug. 2015 Production>

