






- * 3 : Multi-Media Module Receiver Assembly Type
- * 4 : Radio & Display Receiver Assembly Type
- * 8 : 3UR-FE
- * 9 : Except 3UR-FE
- *31 : Before Aug. 2018 Production
- *32 : From Aug. 2018 Production

: There is no wire color information.


F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly



F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly



F18(A), F74(B), F103(C)
Stereo Component Amplifier Assembly

- * 3 : Multi-Media Module Receiver Assembly Type
- * 4 : Radio & Display Receiver Assembly Type
- *24 : w/ Telematics System
- *26 : w/o Telematics System


F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly



F18(A), F74(B), F103(C)
Stereo Component Amplifier Assembly


- * 3 : Multi-Media Module Receiver Assembly Type
- * 4 : Radio & Display Receiver Assembly Type
- * 5 : JBL
- * 6 : PIONEER

F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




F18(A), F74(B), F103(C)
Stereo Component Amplifier Assembly


F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly



F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




t1
No. 1 Stereo Jack Adapter Assembly

- * 1 : w/ Rear Seat Entertainment System
- * 3 : Multi-Media Module Receiver Assembly Type
- * 4 : Radio & Display Receiver Assembly Type
- * 7 : w/ Rear View Monitor
- *24 : w/ Telematics System


: There is no wire color information.



F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly




F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly





F77(A), F96(B), F102(G), F105(H), F107(I), F109(J), F135(K)
Multi-Media Module Receiver Assembly
F118(C), F120(D), F122(E), F124(F)
Radio & Display Receiver Assembly

L66(A), L67(B), L68(C), L77(D), L80(E), L82(F), k1(G)
Multi-Display Controller Sub-Assembly



L66(A), L67(B), L68(C), L77(D), L80(E), L82(F), k1(G)
Multi-Display Controller Sub-Assembly






* 1 : w/ Rear Seat Entertainment System
* 2 : w/o Rear Seat Entertainment System


: There is no wire color information.




L66(A), L67(B), L68(C), L77(D), L80(E), L82(F), k1(G)
Multi-Display Controller Sub-Assembly




L66(A), L67(B), L68(C), L77(D), L80(E), L82(F), k1(G)
Multi-Display Controller Sub-Assembly




L66(A), L67(B), L68(C), L77(D), L80(E), L82(F), k1(G)
Multi-Display Controller Sub-Assembly







- * 1 : w/ Rear Seat Entertainment System
- *10 : w/ Door Control Battery
- *11 : w/o Door Control Battery
- *18 : Liftgate Type
- *19 : Swing Type
- *20 : Liftgate Type w/ Power Back Door
- *21 : Liftgate Type w/o Power Back Door









A 24
Black




A 37
Blue




C 24
Gray



C 44
Blue




E 47
Yellow




E 53
White




E118
White




E119
Black




E122
Black




E133
White




E135
White




E145
Black



E152
Black




E168
Gray




F 6

White




F 7

White



F 8

White



F 13

White




F 14

White




F 18


White




F 74
White




F 75
White




F 76
Black





























F 77
White




F 79
White







L 67
White




L 68
White




L 70
Black




L 77
Brown




L 80
Blue




L 82
Green




P 1
White




P 3
White



P 4
Black




R 7
White




S 8
Black




S 9
Black




S 15
White




S 29
White




S 31
Gray




S 33
Gray















W 3
Blue





c 38
White







CA6
White





EA1
White



EA2

White Gray



EA3

White

