FOREWORD

This wiring diagram has been prepared to provide information on the electrical system of the TOYOTA LAND CRUISER.

English

Applicable models: FZJ 70, 73, 75 Series
HZJ 70, 73, 75 Series
PZJ 70, 73, 75 Series
LJ 70, 72, 73, 77, 79 Series
RJ 70, 73, 77 Series

For information which is not mentioned in this manual, please refer to the following Electrical Wiring Diagram Manuals.

Manual Name	Pub. No.
• Land Cruiser Chassis and Body Repair Manual	RM183E
• Land Cruiser Chassis and Body Repair Manual Supplement	RM192E
• Land Cruiser Chassis and Body Repair Manual Supplement	RM290E
• Land Cruiser Chassis and Body Repair Manual Supplement	RM315E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION