

5 LAND CRUISER
Power Source
Cigarette Lighter and Clock
Power Outlet
1
2
3
4
P15
POWER OUTLET
W
L–R
B–Y
W–B
Right kick panel
IF
C 9
CIGARETTE
LIGHTER
GR
F42
FUSE BLOCK
NO. 1
15A CIG
10A DOME
IH1
C11
CLOCK
10:00
J 1
JUNCTION
CONNECTOR
NO. 1
IE
Left kick panel
From " TAIL" Fuse
<18–4><19–4>
ACC
IG1
ST1
AM1
I11
IGNITION SW
F27
FUSIBLE LINK BOX
FL AM1 1. 25B
BATTERY
(Europe)