
Position of Parts in Instrument Panel

[RHD]



A 7 A/C Amplifier
A 8 A/C Cut Relay (Water Temp.)
A 9 A/C Dual Pressure SW
A10 A/C Thermistor
A15 Ashtray Illumination
A18 Accel Position Sensor
A19 Accelerator Pedal SW
A20 Auto Antenna ECU
A21 Auto Antenna SW

C 9 Cigarette Lighter
C10 Circuit Opening Relay
C11 Clock
C12 Combination Meter
C13 Combination Meter
C14 Combination Meter
C15 Combination SW
C16 Combination SW
C18 Center Diff. Lock Control Relay

D 3 Diff. Lock ECU
D26 Diff. Lock Control SW
D29 DLC3

E 11 Engine ECU
E 12 Engine ECU
E 16 Engine ECU
E 18 Engine ECU
E 19 Engine ECU
E 20 Engine ECU
E 21 Engine ECU

F 33 Front Blower Motor
F 34 Front Blower Resistor
F 36 Front Fog Light SW
F 37 Front Heater Blower SW
F 38 Front Wiper Relay
F 42 Fuse Block No.1
F 64 Fuel Pump Select Relay
F 67 Fuel Tank Changeover SW