ABBREVIATIONS USED IN THIS MANUAL

A/C	Air Conditioner
Approx.	Approximately
A/T	Automatic Transmission
ATF	Automatic Transmission Fluid
A.T.P.	Automatic Transmission Parking
B_O	Overdrive Brake
B_2	Second Brake
B_3	First and Reverse Brake
C_O	Overdrive Direct Clutch
C_1	Front Clutch
C_2	Rear Clutch
CB	Circuit Breaker
ECU	Electronic Control Unit
Ex.	Except
F_O	Overdrive One-Way Clutch
F_2	No.2 One-Way Clutch
Fr	Front
IG	Ignition
LH	Left-Hand
LHD	Left-Hand Drive
LSPV	Load Sensing Proportioning Valve
Max.	Maximum
Min.	Minimum
MP	Multipurpose
M/T	Manual Transmission
OD, O/D	Overdrive
PS	Power Steering
PTO	Power Take-Off
RH	Right-Hand
RHD	Right-Hand Drive
Rr	Rear
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
Temp.	Temperature
VSV	Vacuum Switching Valve
w/	With
w/o	Without
2WD	Two Wheel Drive Vehicles (4×2)
4WD	Four Wheel Drive Vehicles (4×4)