















PREPARATION


SST (SPECIAL SERVICE TOOLS)

EG0AY-0E

	09032-00100	Oil Pan Seal Cutter	
	09155-16100	Spark Plug Wrench	
	09201-15010	Valve Stem Guide Remover & Replacer	
	09202-70010	Valve Spring Compressor	
	09213-58012	Crankshaft Pulley Hoolding Tool	
	09213-60017	Crankshaft Pulley & Gear Puller Set	
	(09213-00020)	Body With Bolt	
	(09213-00030)	Handle	
	(09213-00060)	Bolt Set	
	09213-36020	Timing Gear Remover	
	09223-15030	Oil Seal & Bearing Replacer	Crankshaft rear oil seal
	09228-44011	Oil Filter Wrench	
	09236-00101	Water Pump Overhaul Tool Set	

	(09236–15010)	Bearing Stay	Valve stem oil seal
	09243–00020	Idle Adjusting Screw Wrench	
	09248–66011	Valve Clearance Adjust Tool Set	
	(09248–05310)	Valve Lifter Press	
	(09248–06020)	Valve Lifter Stopper	
	09316–60010	Transmission & Transfer Bearing Replacer	
	(09316–00010)	Replacer Pipe	Crankshaft front oil seal
	(09316–00050)	Replacer "D"	Crankshaft front oil seal
	09330–00021	Companion Flange Holding Tool	Crankshaft pulley
	09608–30012	Front Hub & Drive Pinion Bearing Tool Set	
	(09608–04020)	Handle	Crankshaft rear oil seal Spark plug tube gasket
	(09608–04060)	Front Hub Outer Bearing Cup Replacer	Spark plug tube gasket
	09631–20031	Oil Seal "B" Remover	Conecting rod bushing
	09636–20010	Upper Ball Joint Dust Cover Replacer	Crankshaft timing gear



EG

	09816–30010	Oil Pressure Switch Socket	Knock sensor
	09950–20017	Universal Puller	

EG

EG0AZ–07

RECOMMENDED TOOLS

	*09200–00010*	*Engine Adjust Kit*	
	09258–00030	Hose Plug Set	Plug for the vacuum hose, fuel hose etc.

EG090–01

EQUIPMENT

Battery specific gravity gauge	
Caliper gauge	
CO/HC meter	
Compression gauge	
Connecting rod aligner	
Cylinder gauge	
Dial indicator	
Dye penetrant	
Engine tune–up tester	
Heater	
Magnetic finger	
Micrometer	
Piston ring compressor	
Piston ring expander	
Plastigage	
Precision straight edge	

Soft brush	
Spring tester	Valve spring
Steel square	Valve spring
Thermometer	
Torque wrench	
Valve seat cutter	
Vernier calipers	

SSM (SPECIAL SERVICE MATERIALS)

EG081—0M

08826—00080	Seal packing or equivalent	Over the space between the cylinder block and timing chain case Timing chain cover
08826—00080	Seal packing or equivalent	Semi—circular plug Oil pan Rear oil sear retainer
08833—00070	Adhesive 1324, THREE BOND 1324 or equivalent	Plug tube
08833—00080	Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	BVSV