SS0RK–02

TORQUE SPECIFICATION

Part tightened		N·m	kgf·cm	ft·lbf
Fan set nut		6.4	65	57 in.·lbf
Starter x Transmission		69	700	51
Starter wire x Starter		21	210	15
Front seat x Body		39	400	29
Shift lever boot retainer x Body		4.9	50	43 in.·lbf
Clutch release cylinder x Transmission		12	120	9
Front exhaust pipe x Exhaust manihold		62	630	46
Front exhaust pipe clamp set bolt		19	195	14
Pipe support bracket x Engine		24	240	17
Front exhaust pipe x Center exhaust pipe		42	428	31
LH and RH stiffener plates		69	700	51
Transmission under cover (w/ Sub fuel tank)		18	185	13
Crossmember x Engine rear mounting		74	750	54
Crossmember x Frame		39	400	29
Engine rear mounting x Transmission		59	600	43
Transfer control link set nut (Direct shift type)		20	200	14
Transfer shift lever set nut (Direct shift type)		44	450	33
Transmission x Engine		72	730	53
Transfer shift lever guide (Direct shift type)	Bolt	39	400	29
	Nut	25	250	18
Front drive shift link support shaft (Direct shift type)		88	900	65
Filler and drain plug		37	380	27
Back–up light switch		44	450	32
Clutch housing x Transmission case	w/o Sealant	36	370	27
	w/ Sealant	34	350	25
Control shift lever retainer x Transfer adaptor		18	185	13
Restrict pin		37	380	27
Transmission case x Transfer adaptor		37	380	27
Front bearing retainer x Transmission case		17	170	12
Straight screw plug		19	190	14
Shift fork x Shift fork shaft		20	200	14
Reverse shift arm bracket set bolt		18	185	13
Rear bearing retainer x Intermediate plate		18	185	13