FI0RI–01

INSPECTION

INSPECT ENGINE ECU (See page DI–17)