
RADIATOR SIDE SUPPORT (ASSY)



F16121-A

REPLACEMENT


With the radiator upper support removed.

REMOVAL

〔RHD〕



〔LHD〕




F16123


INSTALLATION

- Temporarily install the new parts and measure each part of the new parts in accordance with the body dimension diagram. (See the body dimension diagram)
- Inspect the fitting of the related parts around the new parts before welding. This affects the appearance of the finish.
- After welding, apply the polyurethane foam to the corresponding parts.
- After welding, apply body sealer and under-coating to the corresponding parts.
- After applying the top coat layer, apply anti-rust agent to the inside of the necked section structural weld spots.

〔RHD〕



〔LHD〕



F16124