F RELAY LOCATIONS

: Center Connector No.1	Behind the Combination Meter (See Page 21)

