
Position of Parts in Instrument Panel

[LHD]



C 8 Center Speaker
C 9 Clock
C10 Combination Meter
C11 Combination SW
C12 Combination SW
C13 Combination SW
C14 Combination SW

D 1 DLC3

E 3 Engine ECU
E 4 Engine ECU
E 5 Engine ECU
E 6 Engine ECU

F 11 Front Passenger Seat Belt Warning Light
F 17 Fuse Holder

G 1 Gateway ECU
G 2 Glove Box Light

H 7 Hazard SW
ODO/TRIP SW
Rheostat
H 8 Headlight Beam Level Control SW
H 9 Heated Oxygen Sensor (Bank 1 Sensor 2)
H10 Hybrid Vehicle Control ECU
H11 Hybrid Vehicle Control ECU
H12 Hybrid Vehicle Control ECU
H13 Hybrid Vehicle Control ECU