

Luggage Compartment Door Opener




B 5(A), B 7(C)
Body ECU
ECUB
From Power Source System (See Page 96)
10A
GAUGE
15A
DOME
J 6
Junction
Connector
C10
Combination Meter
Power Supply
Circuit
(VFD)
BEAN IC
S 7(A), S 8(B), S 9(C), S10(D)
Skid Control ECU
FL+
FL–
FR+
FR–
RL+
RL–
RR+
RR–
SP1
ABS Speed Sensors
GR
B
L
(RHD)
V
(LHD)

Luggage Compartment Door Opener

