

Horn
Power Outlet
Power Source
H 5
Horn (High)
H 6
Horn (Low)
J 2
Junction
Connector
C12
Combination SW
HORN
Theft Deterrent ECU
<1–39>
* 1 : RHD Except Australia, Singapore, Hong Kong
P 6
Power Outlet No. 2
P 5
Power Outlet No. 1
P 7
Power Outlet
Relay
J20(A), J21(B)
Junction
Connector
J24
Junction
Connector
J25
Junction
Connector
15A PWR OUTLET
A15
ACC Relay
25A ACC–B
15A PWR OUTLET FR
7. 5A AM1
P 8
Power Source Control ECU
Multiplex Communication System
(Power Train Control) System<3–9>
HORN Relay
10A HORN
60A P/I
100A DC/DC
120A MAIN
F15
Fusible Link Block
Battery
Cowl Side Panel LH (LHD)
Behind the Combination Meter (RHD)