

■PUNCTURE REPAIR KIT (Option for Europe)

- A puncture repair kit has been adopted on the European models as optional equipment. This kit, which is placed on the vehicle as a substitute for the spare tire, realizes a vehicle weight reduction of approximately 9 kg (19.8 lbs.) as compared to a compact spare tire.
- The puncture repair kit consists of an air compressor, repair seal liquid, insertion pipe, spare valve core, and a valve core remover.



- The repair seal liquid in the kit, which is inserted through the tire valve, seals the punctured area from the inside of the tire. (Repairable area: hole with a maximum diameter of 4mm in the tread area except the sidewalls.)

▶ Use of Puncture Repair Kit ◀



Service Tip

- As with the spare tire, this kit is used only in the event of an emergency. After use, have the tire repaired or replaced at a repair facility as soon as possible.
- Similar to a spare tire, this kit is used for emergency repair. After using this kit, have the tire repaired or replaced at a repair facility as soon as possible.