









FUEL

PREPARATION



023G0–01

SST

	09268–41047	Injection Measuring Tool Set	FUEL SYSTEM(1NZ–FXE)
	(09268–41110)	Adaptor	FUEL SYSTEM(1NZ–FXE)
	(09268–41300)	Clamp	FUEL SYSTEM(1NZ–FXE)
	(95336–08070)	Hose	FUEL SYSTEM(1NZ–FXE)
	09268–45014	EFI Fuel Pressure Gauge	FUEL SYSTEM(1NZ–FXE)
	(09268–41200)	Gauge	FUEL SYSTEM(1NZ–FXE)
	(09268–41220)	Hose	FUEL SYSTEM(1NZ–FXE)
	(09268–41250)	T Joint	FUEL SYSTEM(1NZ–FXE)
	09808–14020	Retainer Tool,Fuel Pump	FUEL SUCTION W/ PUMP & GAUGE TUBE ASSY(1NZ–FXE) FUEL TANK ASSY(1NZ–FXE)
	(09808–01410)	Holder	FUEL SUCTION W/ PUMP & GAUGE TUBE ASSY(1NZ–FXE) FUEL TANK ASSY(1NZ–FXE)
	(09808–01420)	Claw	FUEL SUCTION W/ PUMP & GAUGE TUBE ASSY(1NZ–FXE) FUEL TANK ASSY(1NZ–FXE)
	(09808–01430)	Bolt	FUEL SUCTION W/ PUMP & GAUGE TUBE ASSY(1NZ–FXE) FUEL TANK ASSY(1NZ–FXE)

	09842–30080	Wire "H" EFI Inspection	FUEL SYSTEM(1NZ–FXE)

Recomended Tools

	09082–00040	TOYOTA Electrical Tester	FUEL SYSTEM(1NZ–FXE)
	(09083–00150)	Test Lead Set	FUEL SYSTEM(1NZ–FXE)

Equipment

Clip	
Cutter knife	
Graduated cylinder	
Ohmmeter	
Plastic–faced hammer	
Service wire harness	
Stop watch	
Torque wrench	
Vernier calipers	
Vinyl bag	
Voltmeter	
Wire brush	
Wooden block	

SSM

	08826–00080	Seal Packing Black or equivalent (FIPG)	FUEL INJECTOR ASSY(1NZ–FXE)