












FRONT SUSPENSION

PREPARATION




0238P–01

SST

	09520–01010	Drive Shaft Remover Attachment	FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH
	09520–24010	Differential Side Gear Shaft Puller	FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH
	(09520–32040)	Shocker Set	FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH
	09608–32010	Steering Knuckle Oil Seal Replacer	LOWER BALL JOINT ASSY FRONT LH
	09611–36020	Tie Rod End Puller	LOWER BALL JOINT ASSY FRONT LH
	09628–00011	Ball Joint Puller	LOWER BALL JOINT ASSY FRONT LH FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH STABILIZER BAR FRONT
	09628–62011	Boll Joint Puller	LOWER BALL JOINT ASSY FRONT LH STABILIZER BAR FRONT
	09727–30021	Coil Spring Compressor	FRONT SHOCK ABSORBER WITH COIL SPRING
	(09727–00010)	Bolt Set	FRONT SHOCK ABSORBER WITH COIL SPRING
	(09727–00021)	Arm Set	FRONT SHOCK ABSORBER WITH COIL SPRING
	(09727–00031)	Compressor	FRONT SHOCK ABSORBER WITH COIL SPRING
	09729–22031	Front Spring Upper Seat Holder	FRONT SHOCK ABSORBER WITH COIL SPRING

	09930–00010	Drive Shaft Nut Chisel	LOWER BALL JOINT ASSY FRONT LH FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH
	09950–70010	Handle Set	LOWER BALL JOINT ASSY FRONT LH
	(09951–07150)	Handle 150	LOWER BALL JOINT ASSY FRONT LH

Recomended Tools

	09011–12301	Socket Wrench 30 mm	LOWER BALL JOINT ASSY FRONT LH FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH
	09040–00011	Hexagon Wrench Set	FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH FRONT SHOCK ABSORBER WITH COIL SPRING STABILIZER BAR FRONT
	(09043–20060)	Socket Hexagon Wrench 6	FRONT SUSPENSION ARM SUB–ASSY LOWER NO.1 LH FRONT SHOCK ABSORBER WITH COIL SPRING STABILIZER BAR FRONT

Equipment

Torque wrench	
Dial indicator with magnetic base	
Drill (Safety equipment: epotective goggles, etc.)	Shock absorder disposal
Tire pressure gauge	
Alignment tester	
Toe–in gauge	
Camber–caster–kingpin gauge	
Angle gauge	
Slide Calipers	