













REAR SUSPENSION

PREPARATION



023G2–01

SST

	09710–04101	Base	REAR AXLE BEAM ASSY
	09727–30021	Coil Spring Compressor	REAR SHOCK ABSORBER WITH COIL SPRING
	(09727–00010)	Bolt Set	REAR SHOCK ABSORBER WITH COIL SPRING
	(09727–00021)	Arm Set	REAR SHOCK ABSORBER WITH COIL SPRING
	(09727–00031)	Compressor	REAR SHOCK ABSORBER WITH COIL SPRING
	09950–40011	Puller B Set	REAR AXLE BEAM ASSY
	(09951–04020)	Hanger 200	REAR AXLE BEAM ASSY
	(09952–04010)	Slide Arm	REAR AXLE BEAM ASSY
	(09953–04030)	Center Bolt 200	REAR AXLE BEAM ASSY
	(09954–04020)	Arm 100	REAR AXLE BEAM ASSY
	(09955–04051)	Claw No.5	REAR AXLE BEAM ASSY
	(09957–04010)	Attachment	REAR AXLE BEAM ASSY

	(09958–04011)	Holder	REAR AXLE BEAM ASSY
	09950–60010	Replacer Set	REAR AXLE BEAM ASSY
	(09951–00620)	Replacer 62	REAR AXLE BEAM ASSY
	(09951–00630)	Replacer 63	REAR AXLE BEAM ASSY

Recomended Tools

	09040–00011	Hexagon Wrench Set	REAR SHOCK ABSORBER WITH COIL SPRING
	(09043–20060)	Socket Hexagon Wrench 6	REAR SHOCK ABSORBER WITH COIL SPRING

Equipment

Torque wrench	
Dial indicator with magnetic base	
Wheel balancer	
Tire pressure gauge	
Alignment tester	
Toe–in gauge	
Camber–caster–kingpin gauge	
Drill (Safety equipment: protective goggles, etc.)	Shock absorber disposal